## **NEX-Valve**

### Miniature Non-Elastomer Liquid Valve

8mm Liquid Valve



#### Typical Applications

- Wide Format Printing
- Reservoir Fill / Drain
- Liquid Cooling Systems

Parker's NEX-Valve is a direct-acting, poppet-style valve featuring 2-way bidirectional flow that incorporates many of the proven features of the X-valve®. NEX is inert and eliminates disadvantages commonly encountered in elastomeric valves handling aggressive liquids.

#### **Features**

- Unique non-elastomeric design is compatible found with Alcohols, Solvents, Water and Solvent-based inks
- Power consumption as low as 0.5 Watt: PWM and hit & hold circuit compatible
- Compact and efficient side-by-side mounting
- Ensures high reliability with its single piece body design
- Allows for direct tubing connection or a radial seal for manifold assemblies through its universal barb design
- RoHS compliant



### **Product Specifications**

#### **Physical Properties**

#### Valve Type:

Inert Non-Isolation Valve

#### Valve Configuration:

2-Way Normally Closed

#### Media:

Water, Alcohols, Solvents (The NEX is designed for use with Liquids. If the application requires control of gas please refer to the Parker X-Valve® datasheet)

#### **Operating Environment:**

32 to 122°F (0 to 50°C)

#### **Storage Temperature:**

-40 to 158°F (-40 to 70°C)

#### **Dimensions:**

Length: 0.92 in (23.4 mm) Width: 0.31 in (7.9 mm) Height: 0.48 in (12.2 mm) to Barb End / 0.35 in (8.9 mm) to Manifold Face

Spacing: 0.315 in (8 mm) center

#### Porting:

Barbs for 1/16 in (1.5 mm) I. D. Tubing, (1/32 in Wall Max.) Manifold Mount (Gasket accessory required, see ordering info)

Weight: 0.16 oz (4.5 g) Internal Volume (µL): 74

#### Electrical

Voltage (VDC): 3, 5, 12 or 24 VDC

#### Power (Watts):

0.5 - 0.045" (1.14 mm) orifice 1.0 - 0.030" (0.76 mm) orifice

#### **Connections:**

PC Pins, 4 mm centers Lead Wire/Connector Assembly (Accessory, see ordering info)

#### Wetted Materials\*

#### Bobbin/Body:

PBT (Polybutylene terephthalate)

#### Pole & Plunger:

430 FR Series Stainless Steel

#### All Others:

302 Series Stainless Steel

#### \* See Chemical Compatibility Page Consult factory for other options

#### **Performance Characteristics**

0 to 6 psid (0.4 bar differential) 0 to 30 psid (2.0 bar differential)

#### Orifice Sizes/Equivalent C<sub>v</sub>:

0.045" (1.14 mm) / 0.018 0.030" (0.76 mm) / 0.010

#### **Proof Pressure:**

200 psig (13.7 bar)

#### **Leak Rate: Tested with Water**

< 0.02 sccm @ 6 psi, (Water tight)

#### **Response Time:**

< 20 ms maximum cycling

#### **Recommended Filtration:**

10 micron


#### Reliability:

Life Cycle rating of 1 million cycles (worst case tested, no performance degradation)





# **NEX-Valve** Miniature Non-Elastomer Liquid Valve **Typical Flow Curve**

Flow Rate (sccm)



Pressure (psig)








### **Pressure and Flow Capabilities/Power**


Orifice Size	Nominal Cv	Maximum Operating Pressure Differential *	Power Consumption
0.045 in (1.14 mm)	0.018	6 psid (0.4 bar differential)	0.5 Watt
0.030 in (0.76 mm)	0.010	30 psid (2.0 bar differential)	1 Watt

<sup>\*</sup> Proof pressure is 200 psig (13.7 bar)

### **Electrical Interface**




### **Dimensions**




# **NEX-Valve** Miniature Non-Elastomer Liquid Valve **ANSI Symbols**

#### **NEX-VALVE ANSI SYMBOLS (PRESSURE)**




### NEX-Valve Manifold Mount Diagram



### **Mechanical Integration**

**Dimensions** 

#### Recommended NEX-Valve Manifold Dimensions





### **Chemical Compatibility Chart\***


Chemical	PBT	Stainless Steel
DI Water	1	1
Methanol	1	1
Isopropanol	1	1
Ethanol	1	1
Acetonitrile		1
Tetrahydrofuran	1	4
Toluene	2	4
Organic Acids - Dilute	3	1
Non Organic Acids - Dilute	1	1
Bases - Dilute	1	1
Saline	1	1
Bleach 12%	2	1

<sup>\*</sup>The above is an Abbreviated Chemical Compatibility Chart and is for reference purposes only.

Please consult factory for a complete list.

	COMPATIBILITY LEGEND		
1	EXCELLENT	Minimal or no effect	
2	GOOD	Possible swelling and/or loss of physical properties	
3	DOUBTFUL	Moderate or severe swelling and loss of physical properties	
4	NOT RECOMMENDED	Severe effect and should not be considered	


### **Recommended NEX-Valve Mounting**





### **Typical Flow Diagram**

### NEX-Valve used for solvent control in Printing Application.



### **Accessories**

#### Manifold Rubber Gasket (FKM)

195-000159-001 (required for manifold mounting)

## **12" Wire Leads** 290-006061-001

(for use with Short Pin valve configuration)

# Screw 0-80 x 1/2" Binding Head, Phillips


191-000100-208 (4 required for first valve, 2 more required for each subsequent valve)













### **Ordering Information**

Orifice Size	Pressure	Valve Type	Wattage	Voltage	Electrical Coil Connection	Part Number
				3V	Short Pins	912-000005-011
0.030" 0-30 psid (0.76 mm) (2.07 bar differential)	0.00 ==:d			12V	Short Pins	912-000005-007
	2 Way NC	1.0	12V	Long Pins	912-000005-003	
			24V	Short Pins	912-000005-004	
				24 V	Long Pins	912-000005-008

Orifice Size	Pressure	Valve Type	Wattage	Voltage	Electrical Coil Connection	Part Number
			3V	2\/	Short Pins	912-000005-005
				3 V	Long Pins	912-000005-001
0.045" 0-6 psid (1.14 mm) (0.41 bar differential)	2 Way NC	0.5	5V	Short Pins	912-000005-009	
				Long Pins	912-000005-010	
			12V	Short Pins	912-000005-006	
				1 Z V	Long Pins	912-000005-002
				24V	Long Pins	912-000005-014

Accessories		
195-000159-001: Rubber (FKM) Gasket (1)	(1) Not supplied with the valve. Used as a seal between the valve ports and manifold.	
290-006061-001: 12" (30.5 cm) Wire Leads (2)	(2) Not supplied with the valve. Used to electrically interface with the valve.	
190-006020-001: Retention Pin, PCB (3)	(3) Not supplied with the valve. Used to secure the valve for printed circuit board solder mounting.	
191-000100-208: Screw, 0-80 x 1/2", Binding Head, Phillips <sup>(4)</sup>	(4) Not supplied with the valve. Four (4) screws are required for single station manifold valve mounting. See Recommended X-Valve Mounting for multiple station mounting screw requirements.	

NOTE: In order to provide the best possible solution for your application, please provide the following requirements when contacting Applications Engineering:



- Media, Inlet & Outlet Pressures
- Minimum Required Flow Rate
- System Supply Voltage
- Media
- Ambient Temperature Range

Please click on the Order On-line button www.parker.com/precisionfluidics/nexvalve to configure your NEX-Valve Miniature Inert Non-Elastomer Liquid Valve. For more detailed information, visit us on the Web, or call and refer to Performance Spec. #790-002240-001 and Drawing #790-002241-001 (100 psig) and drawing #890-003090-001 (Standard Pins) and #890-003090-002 (Long Pins).

